



When ESC updating progress was stop, please check below progress to fix the ESC


Connect ESC, Program box, USB cable, PC (it needs ESC turn on)




Open Muchmore Racing FLETA USB Link program and Device on the MENU bar. and then, click the "Fix Mode"




Please check the 'FIRMWARE' icon.




Then, you can choice the firmware what you want to update, even you didn't see the ESC connection icon highlight.



When firmware data is changed to 100% and it turns into a finished, all progress is done.



When want to fix your SHR Program Card, Click the firmware what you want to update. Then click the "PROGRAM CARD FIRMWARE SAVE"



When firmware data is changed to 100% and it turns into a finished, all progress is done.